

#### **Analyze breaker operation**

Activate the FILTER mode to check the current value with the same frequency level as a breaker's operational frequency band, without any effects from the high-frequency components of a switching power source or inverter equipment.



With the FILTER off, an exceedingly high value including high-frequency components is displayed.



With the FILTER on, analysis of breaker operation can be performed.



# **Record the maximum current**

By specifying MAX in the REC (recording) mode, the current value on the display will be updated every time a maximum value is measured. You can then check the transformer capacity, and record the maximum load current.





#### **Specifications**

(Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)

Function	Range	Accuracy	Notes
AC current (AC A)	10.00 mA	±1.0% rdg. ±5 dgt. (45 to 66 Hz) ±2.0% rdg. ±5 dgt. (40 to 45 Hz, 66 to 2 kHz)	Maximum allowable current 20 Arms cont.
	100.0 mA		
	1.000 A		
	10.00 A		
	200.0 A	±1.5% rdg. ±5 dgt. (45 to 66 Hz) ±2.0% rdg. ±5 dgt. (40 to 45Hz, 66 to 2kHz)	Maximum allowable current 200 Arms cont.
Frequency (Hz)	100.0 Hz	±0.3% rdg. ±1 dgt.	Accuracy range 30.0 to 99.9Hz 95 to 1000Hz
	1000 Hz	±1.0% rdg. ±1 dgt.	

AC current measurement accuracy range is 10% to 100% (5% to 100% in 200 A range). Accuracy is given for the filter OFF condition.

# **MARNING**

Inspect the unit and check that it is operating correctly before use. When carrying out measurement on live lines, wear proper protective gear, insulating rubber gloves, insulating rubber boots and safety helmet, and use extreme caution to avoid electric shock accidents.





- 1. In order to prevent short-circuits and injury, use the clamp product on electrical circuits with a voltage less than the maximum operation circuit voltage.
- In order to prevent short-circuits and injury when the clamp core tip is open, do not use bare conductors.

### Record CT 5A or 1A rated output current

Precisely record the current of the secondary side of CTs rated 5A or 1A and below. With ordinary clamp-on meters, large measurement errors result from inputs of only a few amps, and values are displayed inaccurately or simply suppressed to "0A".





Currents of 5A, 1A and below accurately measured and displayed

### Record the average current

Specify AVE in the REC (recording) mode to constantly calculate the average current, and to update the current value on the display. This is useful for recording fluctuating current values.







#### Model: CLAMP ON LEAK HITESTER 3283-20

Model No. (Order Code) (Note)

3283-20 (CE marked, without monitor/analog output)

Accessories: Carrying case 9399 ×1, Hand strap ×1, Alkaline battery (6LR61) ×1, Instruction manual ×1

Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies

HIOKI (Shanghai) SALES & TRADING CO., LTD. TEL +86-21-63910090 FAX +86-21-63910360 http://www.hioki.cn/E-mail:info@hioki.com.cn

DISTRIBUTED BY

## HIOKI E.E. CORPORATION

#### HEADQUARTERS

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 FAX +81-268-28-0568 http://www.hioki.com/E-mail: os-com@hioki.co.jp HIOKI SINGAPORE PTE. LTD. TEL +65-6634-7677 FAX +65-6634-7477 E-mail: info-sg@hioki.com.sg

HIOKI KOREA CO., LTD. TEL +82-2-2183-8847 FAX +82-2-2183-3360 E-mail: info-kr@hioki.co.jp

#### HIOKI USA CORPORATION

TEL +1-609-409-9109 FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com